

How To Program A Dish Remote

Introduction

Few things are more frustrating than settling into your favorite show and realizing your remote control isn't responding the way it should. Whether you have a new DISH receiver, replaced a lost remote, or simply need to control your TV's power and volume with a single device, knowing **how to program a Dish**

essential skill. The good news is that DISH remotes are designed for user-friendly setup, and with a few straightforward steps you can have your remote paired with your receiver and TV in just a few minutes.

This guide walks you through every method available for programming your DISH remote, from automatic code search to manual code entry and even on-screen menu programming.

Downloaded from moveforwardtuhahoma.com by

Alexia & Jeramiah • Books are a uniquely portable magic. • Page 1

We will also cover common troubleshooting issues and advanced tips so that you get the most out of your remote control. By the end of this article, you'll know exactly how to program a Dish remote for any model, and you'll be able to solve most pairing problems on your own.

Understanding Your Dish Remote

Before diving into the programming steps, it is important to identify which DISH remote you own. DISH has released

several remote models over the years, including the 20.0, 21.0, 40.0, 50.0, 52.0, and the newer Voice Remote models with 54.0 or higher. Although the core process for **how to program a Dish remote** remains similar, the button labels and menu paths can vary slightly.

Remote Types and Features

- **Standard Infrared (IR) Remotes** – Require a clear line of sight to the receiver. They use the AUX or TV buttons to control other devices.
- **Hybrid**

How To Program A Dish Remote

IR/UHF Pro Remotes -

Can operate through walls or cabinets.

These are common with DISH Hopper and Wally receivers.

• **Voice**

Remotes -

Include a microphone button and often support Bluetooth for voice commands.

They also use IR to control the TV.

model ensures you follow the correct steps for **how to program a Dish remote** effectively.

Preparation Before Programming

To avoid wasted time, gather the following before you start:

- Fresh batteries for the remote (alkaline recommended)

- Your TV's original remote or the TV brand name and model number.

- Access to the

You can identify your remote by looking at the model number printed on the back of the device or on the battery compartment label.

Knowing your DISH

Automatic

- receiver's front panel (for operations that require pressing the receiver's buttons).
- A list of DISH remote codes for your TV brand (available on DISH's website or in the owner's manual).

Ensure your receiver is powered on and showing a live program. If your remote is completely unresponsive, temporarily use the front panel buttons to navigate.

Method 1:

Programming Using Remote Control Setup

This is the quickest and most common method for **how to program a Dish remote** to control your TV. The remote will automatically scan through its built-in code library until it finds a code that works for your TV's power, volume, and mute functions.

Steps for Standard IR/UHF Remotes

How To Program A Dish Remote

(Models 40.0, 50.0, 52.0)

1. Turn on your TV manually or using its original remote.
2. Point the DISH remote toward the TV.
3. Press and hold the **TV** button on the remote. After about three seconds, the TV button will blink and then remain lit.
4. While holding the **TV** button, press and release the **Power** button. The TV button will turn off.
5. Release the **TV** button. The TV button should blink once.
6. Press the **Power** button repeatedly (once every second). Each press sends a new code to the TV.
7. When the TV turns off, press the **#** (pound) button to lock in the code. The TV button should blink three times to confirm.
8. Test by pressing the **Volume Up** and **Mute** buttons. If they work, programming is complete.

Automatic Programming for Voice

Remotes (54.0 and later)

Voice remotes use a slightly different process. Follow these steps for **how to program a Dish remote** with voice features:

1. Press the **Home** button (three-line icon) on the remote.
2. Navigate to **Settings > Remote Control**.
3. Select **TV Control** or **Program TV**.
4. Choose **Automatic** and follow the on-screen prompts.
5. The receiver will test codes automatically. When the TV

responds (e.g., turns off), confirm the selection.

6. Test the power and volume controls.

This menu-driven approach is the simplest way to **how to program a Dish remote** for newer models.

Method 2: Manual Programming Using Code Entry

If the automatic scan doesn't work or you prefer entering a specific code, manual programming is a reliable alternative. You will need the code for your TV

How To Program A Dish Remote

brand. DISH provides a comprehensive code list on their support page. Common examples include:

- Samsung: 1100, 1103, 1104
- LG: 1003, 1045, 1086
- Sony: 1001, 1002, 1015
- Vizio: 1178, 1179, 1180
- TCL: 1189, 1190

Manual Code Entry for Standard Remotes

1. Turn on your TV manually.
2. Press and hold the **TV** button until it blinks twice and stays lit.

3. Enter the four-

digit code for your TV brand using the number keys. If the code is valid, the TV button will blink three times and turn off.

4. If the TV button blinks twice instead of three times, the code was incorrect. Try another code from the list.
5. Once entered correctly, test the **Volume** and **Power** buttons.

Manual Code Entry for Voice Remotes

1. Press the **Home** button on the remote.

2. Go to **Settings**

Control > Remote Control > Program TV.

3. Choose **Manual** (or **Enter Code**).
4. Type the four-digit code using the on-screen keypad or remote number keys.
5. Confirm and test.

Manual code entry is a tried-and-true method for **how to program a Dish remote** when the automatic scan fails due to compatibility issues.

Method 3: Programming the Dish Remote to

Your TV Using the Dish Menu

For DISH Hopper and Wally receivers, you can program the remote entirely through the on-screen interface. This method is especially helpful if your remote is already paired to the receiver but you want to add TV control.

Steps for On-Screen Programming

1. Press the **Home** button on your DISH remote.
2. Navigate to **Settings > Remote**

How To Program A Dish Remote

- Control.**
3. Select **TV Control** or **Program Remote.**
 4. Choose **TV** as the device you want to program.
 5. Select **Automatic** or **Manual** based on your preference.
 6. Follow the on-screen instructions. The receiver may ask you to point the remote at the TV and press **Power** repeatedly.
 7. Once the TV turns off, press **Select** to lock in the code.
 8. Complete the test steps

screen.

This menu-driven process is part of the easy **how to program a Dish remote** workflow and reduces the chance of button-press errors.

Programmi ng the Remote for a Different TV or AUX Device

One of the hidden strengths of a DISH remote is its ability to control more than just your TV. You can program it to operate a soundbar, A/V receiver, or even a second TV using the

procedure mirrors the TV programming steps but substitutes the **AUX** button for **TV**. For example:

1. Press and hold **AUX** until it blinks twice.
2. Enter the device code (e.g., for a soundbar or receiver).
3. Test the power and volume.

Knowing **how to program a Dish remote** for multiple devices consolidates your home theater control into one hand-friendly unit.

Troubleshooting Common

Issues

Even with clear instructions, you might encounter problems. Here are the most frequent hiccups and solutions:

Remote Not Responding at All

- Check battery orientation and replace them if necessary.
- For IR remotes, remove any obstacles between the remote and receiver or TV.
- For UHF remotes, ensure the remote is **paired** to the

How To Program A Dish Remote

receiver (see pairing section below).

TV Does Not Turn Off During Setup

- If the TV does not respond to any code during the automatic scan, your TV may require a different code range. Try manual code entry by searching for codes online.
- Some TVs, especially older or rare brands, may not be supported. In that case, use the TV's original remote for

volume.

Volume Controls TV but Power Does Not (or Vice Versa)

- Repeat the programming steps but ensure you use the **Power** button for only the function that fails.
- Sometimes the remote captures an incomplete code. Reset the remote (hold **TV** + **Power** until the TV button blinks twice) and try again.

Remote Needs to Be Paired to the Receiver

If your remote isn't

communicating with the DISH receiver at all, it may need to be paired (especially for UHF remotes). To pair:

1. Press and hold the **Home** button on the remote for three seconds. The receiver should respond by displaying “Pairing” on the screen.
2. Alternatively, press the **System Info** button on the receiver’s front panel (or **Power** depending on model). Then press the remote’s **Record** button for three seconds.

3. Follow any on-screen prompts.

Pairing resolves many issues related to **how to program a Dish remote** for receiver control.

Advanced Tips for Optimizing Your Remote

Once you have mastered **how to program a Dish remote**, consider these enhancements:

- **Reset to factory defaults:** If your remote is acting erratically, hold down the

How To Program A Dish Remote

TV button
until it blinks
twice, then

press **Power**
twice. The
remote will
reset.